

HOW TO UPDATE LV-CAN200 USING LV-CAN200 BOOTLOADER V0.2

1. Connect bootloader to USB and PC;
2. Connect bootloader to LV-CAN200;
3. Install drivers “CDM 2.08.28 WHQL Certified” to pc (if need);
4. Launch TeltonikaUpdater.exe;
5. Set login and password:
 - Login: **konstantin.gagac@teltonika.it**
 - Password: **TPBVIEn6**
6. Press “Login” button
7. If updates are available -> Press “Upgrade” button;
8. If need set program number and press “Write”;
9. Disconnect bootloader and mount LV-CAN200 to car.